
ADIRONDACK CHAIR




SKU : LCCZ0695A

Missing part? Damaged? Contact us via email at


service@domioutdoorliving.com

www.domioutdoorliving.com


© Copyright 2024-2026 domioutdoorliving LLC. All Rights Reserved.




① 1X Seat Panel




② 1X Right Leg




③ 1X Left Leg




④ 1X Right Arm




⑤ 1X Left Arm




⑥ 1X Back Panel




⑦ 1X Rear Bar




⑧ 1X Fore Bar



⑨ 2X Bracket




Phone stand
⑩ 1X




Cup Holder
⑪ 1X




M6*30mm Bolt
⑫ 2X



ST6*40mm Screw
⑬ 6X



ST6*50mm Screw
⑭ 2X



M6*50mm Bolt
⑮ 2X




M6*60mm Bolt
⑯ 2X



M6*80mm Bolt
⑰ 4X



M6 Washer
⑱ 10X






⑲ 8X M6 Nut



⑳ 1X Allen Key




㉑ 1X Spanner


Adirondack Chair should include the above parts.

Please inspect box contents to ensure you have received all components.

If you are missing any parts, need assistance with assembly or have questions, please contact our Customer Service.




② 1X	
③ 1X	
⑧ 1X	
⑬ 4X ST6*40	
⑳ 1X	



1

Attach the Fore Bar ⑧ to the chair frame using ST6x40 screws ⑬.



① 1X



⑯ 2X M6*60




⑱ 2X




⑲ 2X



⑳ 1X




㉑ 1X



2


Align the mounting holes on the Seat Panel ① with the corresponding holes on the Right Leg ② and Left Leg ③, insert M6x60 bolts ⑯, secure with washers ⑱ and nuts ⑲, then tighten using the Allen key ⑳ and wrench ㉑ until stable.

④	1X
⑤	1X
⑩	1X
⑪	1X
⑫	2X
⑱	2X





Align the mounting holes on the Right Arm ④ with the corresponding holes on the Cup Holder ⑪, and the mounting holes on the Left Arm ⑤ with the corresponding holes on the Phone Stand ⑩, insert M6x30mm bolts ⑫ with M6 washers ⑱, then tighten until stable.

⑰ 2X M6*80	
⑱ 2X	
⑲ 2X	
⑳ 1X	
㉑ 1X	



Align the mounting holes on the Right Arm ④ with the corresponding holes on the Right Leg ②, insert M6x80 bolts ⑰,secure with washers ⑱ and nuts ⑲, then tighten using the Allen key ⑳ until stable.
Repeat the above steps to secure the Left Arm.


⑥		1X
⑦		1X
⑬		2X ST6*40
⑰		2X M6*80
⑱		2X
⑲		2X
⑳		1X
㉑		1X



Use ST6x40 screws ⑬ to secure the Rear Bar ⑦.
Align the holes of the Back Panel ⑥ with the holes on both Side Arms, insert M6x80 bolts ⑰, secure with washers ⑱ and nuts ⑲.


Please note: do not fully tighten the screws at this stage to allow for position adjustment in the next step.

⑨	2X	
⑭	2X	ST6*50
⑮	2X	M6*50
⑱	2X	
⑲	2X	
⑳	1X	
㉑	1X	




As shown in the image, align the holes of Bracket ⑨, insert the M6x50 bolts ⑮, secure with washers ⑱ and nuts ⑲.
Then use the ST6x50 screws ⑭ to fix Bracket ⑨ at the Back Panel ⑥.
Ensure all bolts are in position before tightening them.

Seatback Adjustment



The chair features three positions for adjusting the Back Panel angle.
Shift between gears by lifting both arms upward and pulling them forward or backward.

Folding Chair



Pull the stick out of both legs to fold this chair as below.

Thanks for your purchase.

At domi outdoor living, we believe in our products. That's why we provide a 12-month warranty and friendly, easy-to-reach after-sales service. So,if you have any questions about our product or assembly, please feel free to contact us. We are here for you.

Support:

After-sales contact email:
service@domioutdoorliving.com

Business cooperation contact email:
marketing@domioutdoorliving.com

Please have your order ID available if you reach out for support.

If you have damaged parts or product, please send us photos for an immediate response.

© Copyright 2024-2026 domioutdoorliving LLC. All Rights Reserved.