

ASSEMBLY INSTRUCTION

AX1PC	BX2PCS	CX2PCS	DX1PC	EX18PCS	FX1PC	GX4PCS
				 M6x30		

1



2



Please note: Our leg tubes have adjustment feet on the bottom. If the chair appears unbalanced, adjust the diagonal leg adjustment feet.